

#### **INTRODUCTION**

Falls are the leading cause of death for workers engaged in residential construction. This document describes various methods that residential construction employers may be able to use to prevent fall-related injuries and fatalities at various points in the residential construction process.

The focus of this document is mostly on new construction. The examples provided in this guidance document do not represent all possible work methods that can be used in residential construction. Moreover, employers should be aware that the examples described in this document may not be suitable in all situations. Employers are responsible for ensuring compliance with applicable Occupational Health and Safety Administration (OSHA) requirements.

Under 29 CFR 1926.501(b)(13), workers engaged in residential construction six (6) feet or more above lower levels must be protected by conventional fall protection (in other words, guardrail systems, safety net systems, or personal fall arrest systems) or other fall protection measures allowed elsewhere in 1926.501(b). (Although the standard does not mention personal fall restraint systems, OSHA will accept a properly utilized fall restraint system in lieu of a personal fall arrest system when the restraint system is rigged in such a way that the worker cannot get to the fall hazard.) If an employer can demonstrate that the fall protection required under 1926.501(b)(13) is infeasible or presents a greater hazard, it must instead implement a written fall protection plan meeting the requirements of 1926.502(k).

Fall protection used to comply with 1926.501(b)(13), including guardrail systems, safety net systems, and personal fall arrest systems, must meet and be used in accordance with applicable requirements in 1926.502. Requirements for work performed on scaffolds, ladders, and aerial lifts are in Part 1926 – Subpart L, Subpart X, and 1926.453, respectively.

State plans may have additional requirements. For further information on state plan standards, please visit osha.gov/dcsp/osp/statestandards.html.

#### **INSTALLING ROOF TRUSSES**

Numerous methods can be used to prevent fall-related injuries and fatalities among workers installing roof trusses.

Bracket Scaffold	A bracket scaffold can be placed on the interior or exterior of a structure. The scaffold can provide a stable working platform. When bracket scaffolds are used on the interior of the structure, the exterior wall can limit employee exposure to fall hazards.  Exterior bracket scaffolds can also be used for installing roof trusses and other rooftop construction activities. The guardrail system on the scaffold can provide fall protection. With the addition of toeboards, falling object protection can be provided to the areas below.
Ladders	Platform ladders and step ladders can provide a stable, elevated platform from which to work.
Anchors	A spreader braces the trusses and distributes arrest forces across several trusses. Spreaders can act as anchors for personal fall arrest systems and fall restraint. They can be reused according to the manufacturer's instructions. It is important to refer to the truss manufacturer's instructions and have a qualified person determine if trusses will meet strength requirements for a personal fall





arrest system or fall restraint system.

### **INSTALLING RIDGE POLES AND RAFTERS**

Although the use of roof trusses is nearly universal, some builders still frame roof systems with ridge poles and rafters. While performing this task, workers need to be protected from falls.

Anchors

Employees installing ridge poles and rafters can use strap anchors and bolt-on anchors. These anchors can be used with personal fall arrest and fall restraint systems to provide fall protection for workers engaged in this activity. Both anchors can be removed and reused according to the manufacturer's instructions.

### **INSTALLING ROOF SHEATHING**

Once a roof has been framed, roof sheathing operations can begin. There are serious fall hazards associated with this activity, but there are a number of ways to protect workers.

Safety Net System	Safety net systems can be used as fall protection for workers installing roof sheathing.
Bracket Scaffold	A bracket scaffold can be attached to the top plate of a structure. The scaffold can provide a secure work platform from which to install roof sheathing.
Anchors	Anchors and retractable lifeline stands can be used by workers installing roof sheathing.

## Roofing - Weatherproofing

As with other roofing activities, fall protection is critical for this type of work.

Bracket Scaffolds	An exterior bracket scaffold can be used for workers weatherproofing a roof. Bracket scaffolds can be especially useful for installing materials along the edge of the roof. Some exterior bracket scaffolds can be used as catch platforms to prevent workers from falling six feet to the lower level.
Anchors	Permanent anchors can be installed during roofing operations and left in place after construction is complete. They can provide an anchorage point during the life of the roof. Reusable anchors can also be used while weatherproofing a roof. It is important to inspect these anchors prior to use.

### Foundation Walls and Formwork

In most residential construction, concrete or masonry block is used to create the foundation and the foundation walls of a structure. The concrete is usually poured into an excavation to create the foundation and the foundation walls.

	Anchors can be added to cured concrete. Anchors with expandable bolts can be placed in holes that have been drilled into the concrete.
	Strap anchors can provide versatility and options for anchorage points while performing this type of work. Strap anchors can be looped over rebar and removed when no longer necessary.
Anchors	These strap anchors can also be poured over with concrete and left in during construction. Antichafe sleeves (the green part of the anchor) can be used to maintain the integrity of the strap. Once no longer needed, the strap can be cut out of the concrete and removed.
	Anchor straps are typically reusable if they have not been poured into concrete or have not been shock loaded. Please refer to the manufacturer's instructions when using this equipment.





**Scaffolds** 

Scaffolds can provide elevated work surfaces for workers performing foundation work.

#### **INSTALLING FLOOR JOISTS AND FLOOR TRUSSES**

Floor joists and floor trusses are usually constructed directly over the foundation walls. Fall hazards may be present, for example, if the structure being built has a basement.

Anchors	A reusable floor truss anchor can act as a temporary truss brace and spacer as well as an anchor point for a self-retracting lifeline. The device can spread shock loads over multiple trusses. These kinds of anchors can be uninstalled, moved, reinstalled and reused as per the manufacturer's instructions.
Scaffolds	Scaffolds can be used for residential construction workers installing floor joists and floor trusses.  Mobile scaffolds can be used effectively for residential construction workers. These scaffolds can be placed on the cured concrete basement floor of a structure. From the elevated platforms of the mobile scaffold, workers can install carrier beams, floor joists, and floor trusses.
Scariolas	Wall bracket scaffolds can be used on a residential structure once a wall has been completed. These scaffolds can provide access around the perimeter of the structure and can be used by workers while they install carrier beams, floor joists, and floor trusses. This type of scaffold can also be used in other phases of residential construction.

### **INSTALLING SUBFLOORS**

Subfloors are usually installed by fastening a wood deck to floor joists and floor trusses. Because of the openings between floor joists and floor trusses, fall hazards may exist while performing this task.

Anchors	A truss bracket anchorage system can distribute the arresting forces across multiple trusses in the event of a fall. When appropriately installed in accordance with the manufacturer's instructions, these anchors can be used with personal fall arrest systems and fall restraints. Because these anchors are reusable, they can be uninstalled and reinstalled in accordance with the manufacturer's instructions.
Guardrails	Guardrail systems can be used to protect workers from falls during the performance of flooring and subflooring activities. If installed with a toeboard, guardrail systems can also protect workers on lower levels from falling objects.

### **INSTALLING WALLS**

Framed wall sections usually are constructed on the ground and typically include sheathing and openings for windows and doors. Guardrails across these openings can help prevent falls while work is being performed in the house after the walls have been erected. These walls can be erected by using a lifting device such as a crane, boom truck, or forklift. Jacks can also be used to raise these walls. These practices greatly reduce the likelihood that a worker will be exposed to a fall during this stage of construction.

Anchors	Some models of strap anchors are looped through soft eyes or larger D rings and can be uninstalled, moved, reinstalled and reused following the manufacturer's instructions.  Strap anchors can also be preinstalled to provide an anchorage point once the walls have been erected and braced. They can be removed by cutting the strap off or pulling out the nails. Once cut or nailed, these must not be reused without being refurbished by the manufacturer.
Guardrails	Guardrail systems can provide fall protection while workers are framing walls.





Aerial Lifts	Aerial lifts may be used for wall sheathing work. In particular, boom type elevating and rotating aerial work platforms can offer positioning flexibility and provide stable elevated platforms.
Scaffolds	Welded end frame (X brace) scaffolds (like tube/coupler and systems scaffolds) stand on their own. With proper bracing, the frames can be stacked from cellar hole to chimney top. Like other scaffolds, these can make stable work platforms for many residential construction operations. These stand-alone scaffolds can be used for sheathing and various other vertical wall operations such as masonry wall construction, siding, and stucco application.
	Exterior bracket scaffolds can provide a work surface from which to attach sheathing to the frame.
	A ladder jack scaffold consists of a platform resting on brackets attached to a ladder. Ladder jacks provide limited elevation and are primarily used in light applications because of their portability and cost-effectiveness.
Sheathing Walls	Although it is common for sheathing to be included on panelized walls used in residential construction, sheathing still takes place on residential construction sites. Erecting the walls by lifting devices or jacks can lessen a worker's exposure to fall hazards.

## **Exterior Finishing**

The exterior finishing phase of residential construction includes a number of activities, such as installing windows, doors, siding, and gutters. Many of these tasks pose fall hazards.

Aerial Lifts	Aerial lifts can be ideal equipment for exterior finishing. By providing a stable, level work surface and positioning flexibility, an aerial lift can be used for numerous activities associated with finishing the exterior of a residential construction structure.
Ladders	Ladders can provide access to areas of a structure where exterior finishing work will occur. They can provide a stable work surface for various exterior finishing tasks.
Scaffolds	Pump jack scaffolds consist of a platform supported by moveable brackets on vertical poles. Pump jacks are appealing for certain applications because they are easily adjusted to variable heights, and are relatively inexpensive. They can include a material shelf for carrying supplies and tools.

### Interior Finishing

Although much of this work may take place while exterior finishing is happening, interior finishing is one of the last phases of residential construction. This does not mean that fall hazards are no longer present.

Guardrails	Guardrails can be an excellent option for providing fall protection for work on or near stairways and
	Guarurans

Source: Occupational Safety & Health Administration



